



Anza

Installation Manual

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.
FOR DOMESTIC USE ONLY, NOT FOR COMMERCIAL USE.

Model: 53056 Matte Black
53283 Fresh White

Fan weight ±0.9 kg / 2 lbs: 7.8 kg / 17.2 lbs

ENERGY STAR

3D INTER*Active* GUIDE

Step 1: Scan QR code with smart phone or tablet

Step 2: Follow on screen instructions

Step 3: Register your product



Our digital guided installation takes you seamlessly from unboxing to completion with clear instructions and visual aids. With the convenience of accessing the guide on your smartphone, tablet, or computer, you can take your installation experience wherever you go.

©2024 Hunter Fan Co.
M4102-01 r112724

Congratulations on purchasing your new Hunter® ceiling fan!

The ceiling fan you purchased will provide comfort and performance in your home or office for many years. This instruction manual contains complete instructions for installing and operating your fan. We are proud of our work and appreciate the opportunity to supply you with the best ceiling fan available anywhere in the world.

We are here to help!

This Instruction Manual is designed to make installation as simple as possible. While working through this Instruction Manual, keep your smartphone or tablet nearby. We have added video links to help you through the more technical sections. If you are unfamiliar or uncomfortable with wiring, contact a qualified electrician. We also provide telephone support at 1.888.830.1326 (Monday - Friday 8am - 6pm CST. Saturday 11am - 4pm CST [English or Español])or visit us at HunterFan.com.

REGISTER TODAY! FREE Limited Lifetime Warranty

To activate your free limited lifetime warranty, please scan the QR code and register your product. This will ensure you receive exceptional service and support for years to come.

SCAN ME

RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

⚠ WARNING



Warning

w.1 To reduce the risk of fire, electrical shock, or personal injury, mount fan directly from building structure and/or an outlet box marked acceptable for fan support of 31.8 kg / 70 lbs and use the mounting screws provided with the outlet box.

w.2 To avoid possible electrical shock, before installing or servicing your fan, disconnect the power by turning off the circuit breakers to the outlet box and associated wall switch location. If you cannot lock the circuit breakers in the off position, securely fasten a prominent warning device, such as a tag, to the service panel.

w.3 To reduce the risk of electric shock, this fan must be installed with an isolating wall control/switch.

w.4 To reduce the risk of personal injury, do not bend the blade brackets when installing the blade brackets, balancing the blades, or cleaning the fan. Do not insert foreign objects in between rotating fan blades.

w.5 Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the product.

w.6 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. It is recommended that children be supervised to ensure that they are not using the appliance improperly.

w.7 - To reduce the risk of fire or electric shock or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3D printer)

Caution

c.1 All wiring must be in accordance with national and local electrical codes ANSI/NFPA 70. If you are unfamiliar with wiring, use a qualified electrician.

c.2 Use only Hunter replacement parts.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2024 Hunter Fan Company
7130 Goodlett Farms Pkwy, Suite 400
Memphis TN 38016

Intertek
This product conforms to
UL Standard 507.


Tools Needed for Installation: (not included)


Box Outlet Mount





Building Structure Mount











Box Contents

Parts Included
















Remote Components




Hardware Included










Assembly required.
For indoor use only.


Before Beginning Installation



Turn Power **OFF**, breaker and light switch.

⚠ WARNING

To avoid possible electrical shock, before installing your fan, disconnect the power by turning off the circuit breakers to the outlet box associated with the wall switch location.




This installation is for **flat ceilings** using the short pre-installed downrod ceiling fans.


IMPORTANT

The **longest** accessory downrod that can be used with HunterExpress® fans is **30.5 cm / 12 inches.**

When using the longer down rod, threadlocker will need to be applied (see Installation–Longer Downrod at the end of this manual for more information.


Room Dimensions






Prep

- You must be able to secure the fan to building structure or fan-rated outlet box.
- You have two options for installation. Pick which one works best for your location. Remove any existing bracket prior to installation.




Using wood screws (**AA**) and washers (**BB**) included, install canopy mount (**A**) through box outlet into building structure.
Drilling 3.16 mm / 9/64 inch pilot holes in building structure will aid in securing canopy mount (**A**).



Install canopy mount (**A**) to box outlet. Secure with machine screws and washers (provided with outlet box).

1b Lever Lock Wiring




Connect wiring from ceiling to lever lock wiring (on side of canopy mount) by lifting lever and inserting wire. Lift lever on connector until fully upright to open. Insert stripped wire and secure by lowering lever. Make sure no bare or uninsulated wire is exposed.

⚠ WARNING

The ceiling fan **must** be grounded. If the ground wire for the installation site is not present, immediately **STOP** installation and consult a qualified electrician.

⚠ WARNING


All wiring **must** be in accordance with national and local electrical codes ANSI/NFPA70. If you are unfamiliar with wiring or in doubt, consult a qualified electrician.




NOTE: Twist wire strands prior to inserting into connector.

Hunter Pro Tip:


Turn the wires upward and push them carefully back through the hanger bracket into the outlet box. Spread the wires apart, with the grounded wires on one side of the outlet box and the ungrounded wires on the other side of the outlet box. Make sure that the wires are still attached to the connectors.




Rotate the downrod into an upright position.



Keep downrod upright and lower downrod adapter cover and twist clockwise until tight.




Install snap-on canopy (**B**) over downrod on fan body (**C**). Place the down rod ball into the slot in canopy mount (**A**) with built-in ceiling bracket.




Slide the remote receiver (**G**) onto top of the canopy mount (**A**). Connect wiring harness from receiver (**G**) to wiring harness from fan body (**C**). Connect wiring harness from canopy mount (**A**) to wiring harness from receiver (**G**).



Connect




Slide the snap-on canopy (**B**) over the canopy mount (**A**) until it clicks in place. Firmly pull canopy down to release it.




Insert the blade (D) into the blade slot around the center screw (C). Put the blade washers (CC) found in the ■ hardware bag onto the blade screws (DD) found in the ▲ hardware bag. Then install the blade screws (DD) to secure each blade to the fan.


Repeat x6




3 Complete




Connect the plugs from the fan (**C**) and light fixture (**E**). Make sure to line up the colored markings on the connectors.



Push the connector and excess wire into the hole at the top of the light fixture. **The connector and excess wiring must be pushed into the light fixture in order to successfully mount the light fixture to the fan.**




Raise the light kit to the bottom of the fan. Align the tabs of the light kit ring with the gaps of the fan mounting plate.




Hold the fan body stationary and rotate the light fixture clockwise to engage the locking pin.

Installation - Final




Align, lift and twist to lock lens cover (**F**) to bottom of fan assembly (**C**).



Turn Power ON, breaker and main switch.

NOTE: On start up your ceiling fan will oscillate back and forth. This is NORMAL OPERATION for DC ceiling fan as it goes through its calibration cycle. The fan is NOT DEFECTIVE.

Operation – Remote



Remote Function Guide

Key Press	Function
+ Quick Press	Light On/Off
+ Long Press	Light Dimming
+ Quick Press	Fan On/Off
△ + Quick Press	Raise Fan Speed
▽ + Quick Press	Lower Fan Speed
+ Long Press	Fan Reverse
Long Press △	Fan High
Long Press ▽	Fan Low

Long Press ▽ + △ Dimming Mode On/Off

NOTICE

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove used batteries promptly.

The remote control is already paired for use. For your convenience a remote function card is packed in with your remote.

Install two AAA batteries, found in the remote control hardware bag, into the transmitter. Clean the battery contacts prior to installing the batteries. Please contact your local battery recycling center for proper battery disposal information.

Troubleshooting

Fan Does Not Work

- Make sure power switch is on.
- Check the circuit breaker to ensure the power is turned on.
- Make sure the blades spin freely.
- Turn off power from the circuit breaker, then loosen the canopy and check all the connections according to the wiring diagram.

Excessive Wobbling

- Make sure the blades are properly installed on the blade iron posts.
- Turn the power off, support the fan carefully, and check that the hanger ball is properly seated.

Remote Control of Fan is Erratic

- Make sure the batteries are installed correctly.
- Install fresh battery.

Remote Only Works Close to Fan

- Change battery.

Noisy Operation


- Make sure the blades are properly installed.
- Check to see if any of the blades are cracked. If so, replace all of the blades.

Multiple Remote Issues

- If you have multiple remotes or multiple remote controlled fans installed on the same circuit breaker and you are experiencing interference or f aulty operation of your remote controls, please go to www.HunterFan.com/FAQs and click “How do I properly install multiple remote-controlled fans?” for information on how to correct this issue.

Light Does Not Work

•Disassemble the light kit and check the wiring connection according to the light kit installation. Remove the globe by twisting counter clockwise. Remove the three LED module screws to remove LED module. Ensure that the plugs are connected and secure. Reassemble light kit and test functionality.



Limited Lifetime Warranty

Hunter Fan Company grants this limited warranty to the original purchaser of this Hunter ceiling fan. This document can be found at www.HunterFan.com. Thank you for choosing Hunter!

How Can Warranty Service Be Obtained?

Proof of purchase is required when requesting warranty service. The original purchaser must present a sales receipt or other document that establishes proof of purchase. Hunter, at its sole discretion, may accept a gift receipt. To obtain service, contact Hunter Fan Company online or by phone.

www.HunterFan.com/Support/Contact-Us/
1-888-830-1326

Please do not ship your fan or any fan parts to Hunter. Delivery will be refused.

What Does This Warranty Cover?

Motor — Limited Lifetime Warranty

If any part of your ceiling fan motor fails during your ownership of the fan due to a defect in material or workmanship, as determined solely by Hunter, Hunter will provide you with a replacement fan free of charge.* The foregoing limited warranty applies only to the motor itself and does not apply to electronic controls – such as remote control transmitters, remote control receivers, or capacitors – used in conjunction with the motor. Such electronic control items are included in the Three-year limited warranty below.

Other — Three-Year Limited Warranty

Except as otherwise indicated throughout this warranty, if any part of your Hunter ceiling fan fails at any time within three years of the date of purchase due to a defect in material or workmanship, as determined solely by Hunter, Hunter will provide a replacement part free of charge.*

** If no replacement product/part can be provided for your fan, we will provide a comparable or superior replacement product/part at the sole discretion of Hunter.*

What Does This Warranty NOT Cover?

Labor Excluded. This warranty does not cover any costs or fees associated with the labor (including electrician’s fees) required to install, remove, or replace a fan or any fan parts.

There is no warranty for light bulbs; remote control batteries; fans purchased or installed outside the United States; fans owned by someone other than the original purchaser; fans for which proof of purchase has not been established; fans purchased from an unauthorized dealer; ordinary wear and tear; minor cosmetic blemishes; refurbished fans; and fans that are damaged due to any of the following: improper installation, misuse, abuse, improper care, failure to follow Hunter instructions, accidental damage caused by the fan owner or related parties, modifications to the fan, improper or incorrectly performed maintenance or repair, improper voltage supply or power surge, use of improper parts or accessories, failure to provide maintenance to the fan, or acts of God (e.g. flood).

ORIGINAL PURCHASER’S SOLE AND EXCLUSIVE REMEDY FOR A CLAIM OF ANY KIND WITH RESPECT TO THIS PRODUCT SHALL BE THE REMEDIES SET FORTH HEREIN. HUNTER FAN COMPANY IS NOT RESPONSIBLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, DUE TO PRODUCT FAILURE, WHETHER ARISING OUT OF BREACH OF WARRANTY, BREACH OF CONTRACT, OR OTHERWISE. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE APPLICABLE TO THIS PRODUCT ARE LIMITED IN DURATION TO THE PERIOD OF COVERAGE OF THE APPLICABLE LIMITED WARRANTIES SET FORTH ABOVE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.


How Does State Law Affect Warranty Coverage?

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Using a Different Size Downrod


If you need a different downrod length follow these steps:

STEP 1




In order to change the length of downrod, the pivot assembly needs to be disengaged. Rotate the downrod into an upright position.

STEP 2




Disengage retention spring by pulling away from rod. Then remove cross pin from downrod. Remove downrod assembly from pivot assembly.

STEP 3




Remove ball screw (1).

STEP 4




Slide ball down (2), remove small metal pin (3) and ground screw (4).

STEP 5




Slide down inner sleeve (5).

STEP 6




Remove ball, inner sleeve, downrod (6), and adapter cover.

STEP 7




Route ground wire and wiring harnesses through accessory downrod–30 cm / 12 inch max. (7). Slide adapter cover, inner sleeve and ball over downrod (8).

STEP 8




Slide up inner sleeve (9).

STEP 9




Reinstall small metal pin (10) and ground screw (11). Slide ball up (12).

STEP 10




Reinstall ball screw (13).

STEP 11




Place downrod assembly between the pivot bracket and make sure pivot bracket holes and downrod holes are aligned.

STEP 12



Push the retention spring to the side to allow cross pin access. Place cross pin through downrod assembly and the pivot bracket. Place retention spring into the groove of the cross pin.

STEP 13



Keep downrod upright and lower downrod adapter cover and twist clockwise until tight.

⚠ WARNING

FAN FALL HAZARD

To prevent **SERIOUS INJURY** or **DEATH:**

- **ALWAYS** follow the downrod assembly instructions exactly.
- **VERIFY** the downrod is assembled correctly by firmly pulling on the hanger ball.

Made in China

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com