



Model 99983

HunterSMART™ Plug Quick Start Guide

Our step-by-step digital installation guide takes you from unboxing to setup with easy-to-follow instructions and helpful visuals. With easy access through your smartphone or tablet, so you can set up your HunterSMART Plug wherever it's most convenient. Turn everyday devices into smart devices with the HunterSMART Plug using Matter. Easily connect with your favorite smart home platforms like Amazon Alexa, Apple Home, Google Home, and SmartThings. Just plug in any corded device like a lamp, fan, or small appliance to instantly enjoy Wi-Fi control, scheduling, automation, and voice commands. A Matter controller is needed, which may be a smart speaker you already own like Echo, HomePod or Nest Hub.



Connect to HunterSMART™

Download the **HunterSMART App** by scanning the QR code here or searching "HunterSMART" in your app store.



- In the app, select add device, then follow the on-screen prompts in the app.
- When prompted, scan the QR code displayed on your plug to connect.

3D INTERActive GUIDE

Step 1: Scan QR code with smart phone or tablet


Step 2: Follow on screen instructions

Step 3: Register your product



SCAN ME

- 1 Scan the QR code on the back of the plug and insert the HunterSMART Plug into a power outlet.



- 2 Press the power button on the plug to turn it on.



- 3 Hold the power button for up to 10 seconds for up to 10 seconds until the light blinks blue, indicating it's ready to pair.



Operation Cycle: 10 000 (Manual)

Disconnection Type: Micro-Disconnection

Type 1 Action: 1.B

Pollution Degree: 2


Rated Impulse Voltage: 1500V

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This product conforms to UL Standard 60730 and 498A.



Function	Connection Indicator
Factory reset	Blue rapidly flashes
Product on (ready to connect)	Blue light flashes
Product on and connected	Blue solid
Product disconnected	Red light flashes

Tips & Tricks

- **Cross-Ecosystem Flexibility:**

Because it's Matter-certified, the plug works seamlessly across ecosystems. Set it up in whichever app you prefer, no proprietary app required. A Matter controller is needed, which may be a smart speaker you already own like Echo, HomePod or Nest Hub.

- **Control More with a Power Strip:**

Control multiple devices at once as a single On/Off grouping. Ensure the combined load stays within the 10A/1200W capacity.

- **Hands-Free Control:**

Pair with your favorite smart assistant to turn devices on or off with just your voice.

- **On/Off Schedule:**

Use your preferred smart home platform to schedule on/off times automatically.

- **Easily Set Automations and Routines:**

Use your smart home app to schedule lights or devices to power On/Off automatically — perfect for routines or added security while away.

- **Indoor Use Only:**

This plug is not rated for use outdoors or in damp areas.

- **Factory Reset:**

Press and hold the power button for 10 seconds until the LED blinks blue rapidly.

Warranty

We've Got You Covered:

1-Year Limited Warranty

The Hunter Fan Company makes the following limited warranty to the original purchaser of the Control ("Control"): Your Control is warranted to be free from defects in material and workmanship for a period of one year from the date of sale. If the Control malfunctions or fails within the warranty period due to a defect in material or workmanship we will replace it free of charge. IF THE ORIGINAL PURCHASER CEASES TO OWN THE CONTROL, THIS WARRANTY AND ANY IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE VOIDED. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. THE DURATION OF ANY IMPLIED WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IN RESPECT TO ANY CONTROL, IS EXPRESSLY LIMITED TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE FOR SUCH CONTROL. This warranty excludes malfunctions or failures which were caused by repairs by persons not authorized by us, mishandling, improper installation, modifications, or damage to the Control while in your possession, or unreasonable use. To obtain a replacement, return your Control postage prepaid along with proof of purchase to Hunter Fan Company Service Department at 7130 Goodlett Farms Pkwy., Memphis, TN 38016. IN NO EVENT SHALL HUNTER FAN COMPANY BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

For full details or support, [visit support.hunterfan.com](https://support.hunterfan.com).